

Digital TD Controller

Dante Firmware Update Procedure

This document presents how to update the Dante part of the DTD-T-N or DTD-I-N devices step by step.


PRESENTATION

NEXO Dory is a remote control software intended to be used with NEXO Devices that have a USB control port to update and control them. At the time of writing, the Digital TDcontroller (DTD) is the only NEXO device that is compatible with Dory. The DTD can have a Dante input which is available as an option. This Dante module can be upgraded as well.

UPGRADING THE DANTE FIRMWARE

Launching Dante Updater

First, install the latest version of Dante Controller available on the official website of [Audinate](#). Dante Updater can be accessed through the interface of Dante Controller. To launch Dante Updater, click on the button in the main toolbar as shown below:




If Dante Updater identifies one or more DTD devices on your Dante network for which new firmware is available, a notification icon is displayed on the Dante Updater button in the main toolbar:



Checking Device Status


The application is linked to an online database containing firmware update files for products from multiple manufacturers. If newer firmware for any device is available in the online database, you can update the device using the online file, or download the firmware file to your local machine for offline use:





The Dante Updater will display the devices that need to be updated in the section “Update(s) available”. If firmware is found for multiple devices in your network, you can choose to update all devices simultaneously.

Updating DTD Devices

Click on the “Update selected device(s)” button to start update:




A warning message will warn not to power off the device(s) and to inform that the audio will be interrupted. Then, the update progress is displayed until the end.



After update successful, the DTD device must be rebooted. The device will be displayed in the “Up-To-Date” section of the main view where you can always easily

control which devices get updated or not.



For more information, please follow the link below to access the online documentation of Dante Updater: [Dante Updater User Guide](#)

Feedback and Bug Reporting: technical@nexo.fr. Thanks for your cooperation!

NEXO SA cannot be held responsible for damages caused by improper use of the devices and its manual.

The screenshots shown in this document may vary with the considered language and version.

Dante and Dante logo are trademarks of Audinate Pty Ltd.

NEXO SA
PARC D'ACTIVITE DE LA DAME JEANNE
F-60128 PLAILLY

Phone: +33 3 44 99 00 70

Fax: +33 3 44 99 00 30

Email: info@nexo.fr

Web site: www.nexo-sa.com