




DP2490/Rev01a - DI

# **Quick Release Truss Clamp**


(25 > 38 mm truss capacity)







#### **Contents:**




Weight: 0.75 kg / 1.65 lb




- Read this document before using.
- Keep this document.Observe all warnings and cautions.


#### **Dimensions:**



# Assembly:




# Implementation:







- Read this document before using.Keep this document.Observe all warnings and cautions.


#### Use:





- Never exceed the Safe Working Load (SWL) shown on the clamp.
- Only use the clamp within the designed tube parameters (25-38mm).
- All clamps should be visually inspected before use. In the event of any damage, the clamp should be taken out of service and returned to an 'Approved NEXO Service Agent' for inspection.
- When used in conjunction with other accessories, care must be taken to ensure that the minimum SWL of any components is not exceeded.
- All open clamps including hook clamps should be used in a vertical orientation only.








Keep this document.Observe all warnings and cautions.

# Warning:



- NEXO cannot accept responsibility for accidents caused by any factor other than defects in this product itself.
- Please check the web site www.nexo-sa.com for the latest update.



- Read this document before using.Keep this document.Observe all warnings and cautions.